

# Yunity

## Installation Manual

V2025



Do you know we offer  
professional installation  
service?  
Please scan the QR to find  
your local installer




# Table of Contents


What's Included	1
Product Overview	2
Drill Connecting Cable Hole	3.1
Install the Cylinder	3.2
Prepare the Internal Panel	3.3
Check Existing Screw Holes	3.4
Install Screw Stub C	4a.1
Prepare the Fixing Screws	4a.2
Install the External Panel and Mounting Plate	4a.3
Install Screw D	4b.1
Install the Adaptor and Cylinder Sleeve	4b.2
Remove the Sleeve and Cylinder	4b.3
Install the External Panel	4b.4
Install the Mounting Plate	4b.5
Connect the Cable	5.1
Install the Internal Panel	5.2
Install the Batteries	5.3
Install the Battery Cover	5.4

What's Included


1




External Panel



Adapter




Mounting Plate




Internal Panel



⊕ A×3




⊕ B×9




⊕ C×3




⊖ D×3



tail bar




⊕ E×4



⊕ F×1

⊕ G×1




Cylinder



Cylinder Sleeve






Drill Connecting Cable Hole

3.1


Use the template provided to drill a hole with a diameter of  $\phi 20$  on the door.



Install the Cylinder


3.2

Select and replace the appropriate tail bar according to the thickness of the door.  
Install the cylinder and secure it with screw G.



When the lock body is Centered.

Door Thickness/mm	Length of the tail bar
40-54mm	25mm
54-68mm	32mm
68-80mm	39mm




Warning!

After the cylinder is installed, please make sure that the tail bar protrudes 9 - 16 millimeters from the door.

Prepare the Internal Panel


3.3



Check Existing Screw Holes

3.4


Are there two screw holes with centre distance 38mm on the door as illustrated?



## Install Screw Stub C


4a.1

Install 3 screw stub C onto the back of external panel.




## Prepare the Fixing Screws

4a.2



## Install the External Panel and Mounting Plate

4a.3




1. Place the external panel onto the door.
2. Slide the cylinder sleeve onto the cylinder, ensuring it's fully inserted.
3. Use the 3 prepared screws E to attach the mounting plate to the external panel.
4. Secure the mounting plate to the door using 2 screws B.
5. Finally, remove the cylinder sleeve. Proceed to Step 5.

## Install Screw D

4b.1


Install 3 screw D onto the back of external panel.



## Install the Adaptor and Cylinder Sleeve


4b.2

1. Slide the cylinder sleeve onto the cylinder, ensuring it's fully inserted.
2. Secure the adaptor to the door using 4 screws B.



## Remove the Sleeve and Cylinder

4b.3




1. Remove the cylinder sleeve.




2. Remove the cylinder .

## Install the External Panel

4b.4



1. Attach the external panel to the adaptor.
2. Adjust screw F based on door thickness.
  - 40-55mm: No screw F required;
  - 55-70mm: Cut off 10mm from screw F;
  - 70-80mm: Use screw F without cutting;
  - Off-centre lock body: Cut and use screw F accordingly.
3. Thread screw F into the cylinder's bottom hole, then secure the cylinder back into the door with screw G.




### Important!



When installing the cylinder, make sure that portion of screw F protrudes into the external panel's cylinder hole, preventing panel removal.

## Install the Mounting Plate


4b.5



1. Slide the cylinder sleeve onto the cylinder, ensuring it's fully inserted.
2. Secure the mounting plate to the door using 5 screws B.
3. Finally, remove the cylinder sleeve.


## Connect the Cable

5.1




## Install the Internal Panel

5.2




## Install the Batteries


5.3



## Install the Battery Cover

5.4





Please scan the QR to  
get the newest  
manuals on Blusafe  
products



Find out more about  
Blusafe vulnerability  
discovery & disclosure  
procedures